

Fitting Guidelines for Lean-to 1050mm; 1200mm or 1400mm Canopy **(Ellesmere design)**

Thank you for purchasing a canopy from us.

It is advisable to paint or stain your canopy prior to installation, so that it's possible to paint the surfaces which will go to the wall, giving better protection to the timber.

The usual method of installation is as follows: -

1. Mark the centre of the door frame and then measure either 525mm/ 600mm or 700mm back from the centre mark, either side.
2. Drill and fix with 100mm screws and plugs, the side brackets to the marks. Ensure you have several good fixings to each bracket.



3. Fix the rear wall plate with 100mm screws to the back wall and to the side brackets. The top of the rear wall plate should be fixed level with the bottom of the rebate on the side bracket (see picture below). The rear wall plate is the exact same length as the canopy width that you have ordered.



4. Fix the front wall plate into position with screws. It should project either side of the side brackets by 10mm.



5. Drill and fix with screws, the centre rafter/s.



6. Starting at the bottom, fix the tongue and groove boards with panel pins.



7. Finish the boarding. The top board will need to have a square cut out of it.



8. Fix the small wooden wedge level with the end of the rafter. The fascia board can now be fitted level with the top of this wedge.



The canopy is now ready for your roof covering to be applied.

If you require any help or advice, please do not hesitate to contact us on 01691 623737 or email: sales@shropshiredoorcanopies.co.uk

If you have purchased your canopy from us via Ebay, we would be grateful if you could leave us feedback.